

**Topic:**  
Matrox Board, DOS Diagnostics

***VXServices, LLC***  
1230 Hunter Court, Longmont, CO 80501  
Voice 303-651-6519 Fax 303-651-7693

## Solution Report

### **Symptoms/Condition:**

Low level testing of Matrox Board is required.

### **Solution:**

Boot the computer into DOS.

Change to the Matrox directory.

Execute "**imdiag -LC**" with proper flags:

- **-a** (for first board)
- **-a -2** (for second board)
- **-LD** (to repeat test continually)

or **imdiag -help** for usage.